



# INSTALLATION MANUAL

## FlexCAP



## FlexCAP - FB



**NOTE:** nuts and bolts are not included.

Examples of incorrect instalment. Use the supplied cork washers to prevent mount from rotating. Make sure not to overtighten the nuts to prevent the mount from twisting.

